



GIGA01002 Rippled Curvatura 9x Product Guide

What's Included

- Product
- Warranty Card/Instructions
- USB Charger

Operational Notes

- 9 Modes
- Rechargeable
- Waterproof - Submersible
- Do not use silicone lubricant with silicone products

1



Power Button

Press power button for 3 seconds to turn device on and hold for 2 seconds in any function to turn the device off.

2

Power/
Function
Button



Switch between functions by pressing the power button and cycling through modes. Backlight will flash with vibration patterns. Once modes have cycled through, the device will stop vibrations, but remain on. This is indicated by a solid blue backlight behind the power button.

3



Charge Port

Charge your toy by locating the charging port at the back of the device. After connecting the USB cable to a power source, insert the other end of charger to the DC outlet. Press the charging pin through silicone seal. This will not affect waterproof functionality.

4



Backlight will flash blue when charging. It will stop flashing once the device is fully charged.

