



GIGA04006 Warm Me Wabbit 10x Product Guide

What's Included

- Product
- Warranty Card/Instructions
- Magnetic EZ-click USB Charger

Operational Notes

- 10 Modes
- Magnetic USB Charging
- Warming Feature
- Waterproof - Submersible
- Do not use silicone lubricant with silicone products



1

Top and bottom arrows toggle functions. Power button on the left, warming button on the right. Press and hold power button (three seconds) to turn device on/off.

Control Pad



2

Functions


Power Button



Backlight will illuminate when buttons are pressed. Toggle functions by using the up and down arrows on the control pad.


3

Warming Feature



Press the flame button once to activate warming mechanism. Backlight will turn a light red color. Press and hold warming button to turn off. Device takes around two minutes to heat up along the shaft. Once the device has warmed to max temperature, the backlight will turn white. The device will slowly decrease in temperature and you must then press the flame button again to re-activate warming feature.

4



Magnetic charging mechanism is located on back of the device. When device is charging, backlight on control pad will flash and become solid when fully charged.

